



1 Panel Mounting

- Fix the panel to the wall using 4 screws.
- Six-push through holes are available for installing the PG11 glands.
 1. Power supply
 2. Outputs 1 & 2 and relays 1 & 2
 3. Outputs 3 & 4 and relays 3 & 4
 4. Outputs 5 & 6 and relays 5 & 6
 5. Outputs 7 & 8 and relays 7 & 8
 6. JBUS/MODBUS
- Knock out the push-through holes from the outside.
- Connect all plug-in terminals (refer to step 2).
- Plug the terminals.
- Close the box, starting by inserting the top side, and then push the bottom down. Lock, using the two available screws.
- Power up from the circuit-breaker.

2 Electrical Connections

- Connect the sense cables following this color code:
 - A: Green
 - B: White
 - C: Black
 - D: Red

Terminate unused outputs with two loops between the A&B and C&D connectors.

The wiring diagram is on the back page.
- Connect the relays:
 - COM: Common
 - NC: Normally Closed
 - NO: Normally Open
- Nine relays are available on FG-ALS8:

Relay 1 = leak zone 1	Relay 2 = leak zone 2
Relay 3 = leak zone 3	Relay 4 = leak zone 4
Relay 5 = leak zone 5	Relay 6 = leak zone 6
Relay 7 = leak zone 7	Relay 8 = leak zone 8
Relay 11 = cable-break all zones	
- Connect the power supply following the signs:
 - Ground sign: Ground
 - N: Neutral
 - L: Line

Power supply: 100-240 V AC 50/60 Hz 0.25 A

3 Capacity

The FG-ALS8 panel is designed to receive up to 100m (328 ft) of sense cable (FG-ECS, FG-ACS, FG-ECX, FG-ACX) per zone.

4 Powering-on the System

Power on from the circuit breaker:
 The panel will sound and show "SYSTEM TEST" for 20 seconds on the display, and will then show the "home" screen:



■ Touch the first button (flag) to change the language:
 English
 French
 German
 The language setting will affect the bottom banner and the texts in the alarm screen.

■ Touch the second button (arrows) to show the lengths installed in each of the 4 zones (please refer to step 5).

■ Touch the third button (gears) to change the MODBUS slave number.

5 Settings

- Touch the second button (arrows), the touch screen shows the lengths installed on each of the four cables:

ZONES

Zone 1: 15m Zone 5: 7m
 Zone 2: 30 m Zone 6: 30
 Zone 3: 60 m Zone 7: 15m
 Zone 4: 7m Zone 8: 45 m




■ Touch the "home" button to return to the main page.

■ Touch the "refresh" button (arrows) to update the lengths displayed.

The system will return to the "home" screen after 30 seconds of inactivity.

- Touch the third button (gears) to change the Modbus slave number.



- Alarm screen:

If a fault occurs (leak or cable-break), the leak alarms are represented by a drop of liquid;

Cable-break alarms are represented by scissors and the "sensor" label.

ZONES

1: SENSOR 5: SENSOR
 2: 30 m 6: OK
 3: 99 m 7: SENSOR
 4: OK 8: 45 m



The system will return to the "home" screen after 30 seconds of inactivity.

6 MODBUS

The MODBUS protocol implemented on FG-ALS8 allows the current status of the system to be supervised. The two types of alarm (leak and cable-break) are coded using different Modbus registers for each individual zone.

The physical support of the MODBUS is two-wire RS485.

Serial port configuration	9600 B, 8 data bits, 1 stop bit, no parity
Communication protocol	MODBUS or JBUS, functions 3 or 4
Maximum number of FG-ALS connected to the same controller	31
Slave number	1 to 247
Maximum number of reading registers	16
MODBUS Addresses in the memory	<p>Register 1 = length zone 1 Register 2 = leak zone 1 Register 3 = cable-break zone 1 Register 4 = leak location zone 1</p> <p>Register 5 = length zone 2 Register 6 = leak zone 2 Register 7 = cable-break zone 2 Register 8 = leak location zone 2</p> <p>Register 9 = length zone 3 Register 10 = leak zone 3 Register 11 = cable-break zone 3 Register 12 = leak location zone 3</p> <p>Register 13 = length zone 4 Register 14 = leak zone 4 Register 15 = cable-break zone 4 Register 16 = leak location zone 4</p> <p>From register 17 to 32 for zones 5, 6, 7, 8</p>

Format of the solution:

Slave number	Function	No. of bytes read	Byte 1	Byte 2	...	Byte N	CRC 16
1, 2, ..., 247	3 or 4	up to 32	XXh	XXh	...	XXh	XXXXh


- Remarks:

The last panel on the serial link should be terminated by a 120 Ohms / 1W resistor between points RT- and RT+. The shielding of the data transmission cable should be connected to the controller's earth and to the terminal COM of each FG-ALS8 panel.

- Slave number 0 inhibits the MODBUS operation.

It is advisable to leave at least 200 ms between the successive requests.

TTK WIRING DIAGRAM / FG-ALS8



Although carefully prepared to ensure technical accuracy, this brochure is intended for promotional use only. TTK cannot guarantee that the information contained herein is free of errors or omissions, and hence does not accept liability related to the use of its equipment. TTK maintains its obligations set out in the Standard Terms and Conditions of Sale and will not, under any circumstances, assume liability for any incidental damages, indirect or consequential, arising from the sale, resale, use or misuse of this product. All purchasers accept their responsibility as sole judge of the suitability of the product for the intended use. FG-NET, FG-SYS and TOPSurveillance are trademarks of TTK S.A.S. © TTK 2021

- **TTK Headquarters** / 19 Rue du Général Foy, 75008 Paris, France / T: +33.1.56.76.90.10 / F: +33.1.55.90.62.15 / www.ttk.fr / ventes@ttk.fr
- **TTK UK Ltd.** / 3 Luke Street London EC2A 4PX / United Kingdom / T: +44 20 7729 6002 / F: +44 20 7729 6003 / www.ttkuk.com / sales@ttkuk.com
- **TTK Pte Ltd.** / #10-08, Shenton House, 3 Shenton Way / Singapore 068805 / T: +65 6220.2068 / M: +65 9271.6191 / F: +65 6220.2026 / www.ttk.sg / sales@ttk.sg
- **TTK Asia Ltd.** / 2107-2108 Kai Tak Commercial Building / 317 Des Voeux Road Central / Hong Kong / T: +852 2858.7128 / F: +852 2858.8428 / www.ttkasia.com / info@ttkasia.com
- **TTK Middle East FZCO** / Building 6EA, Office 510 PO Box 54925 / Dubai Airport Free Zone / UAE / T: +971 4 70 17 553 / M: +971 50 259 66 29 / www.ttkuk.com / cgalliche@ttk.fr
- **TTK Deutschland GmbH** / Berner Strasse 34, 60437 Frankfurt / Germany / T: +49 (0)69-95005630 / F: +49(0)69-95005640 / www.ttk-gmbh.de / vertrieb@ttk-gmbh.de
- **TTK North America Inc** / 1730 St Laurent Boulevard Suite 800 / Ottawa, ON, K1G 5L1 / Canada / T: +1 613 566 5968 / www.ttkcanada.com / info@ttkcanada.com
- **Thomas Sales & Marketing Inc. TTK Master Distributor For USA** / 7200 W 66th St / Bedford Park, IL 60638 / USA / T: +1 630-518-4724 / www.ttkusa.com / dmlk@ttkusa.com